

Wireless Baseball

USER'S GUIDE



dreamGEAR®
www.dreamgear.net

PACKAGE CONTENTS:

- 1 Wireless Baseball Bat Controller
- 1 Wireless Game Pad
- 1 Infrared Sensor

BATTERY INSTALLATION:

1. Install 2 "AAA" batteries into the wireless Baseball Bat controller.
2. Install 3 "AA" batteries into the wireless Game Pad.
3. Install 3 "AA" batteries into the Infrared Sensor.

SET-UP:

1. Locate the infrared sensor with the attached AV cable and plug it into the AV inputs on your television. Power "ON" the infrared sensor by switching the power switch to the "ON" position. Power "ON" the Baseball Bat by switching the power switch to the "ON" position". Make sure your TV is set to the proper video input.
2. Select Baseball on the home menu and begin game play.
3. The Baseball game is played by swinging the bat. The buttons on the bat are used for making menu selections.

PLAYING THE BONUS GAMES:

1. Turn the power switch on the game controller to the "ON" position. To play the included bonus games, push the start button located on the game controller. Use the directional pad to select the game you would like to play. Press the start button to make your selection.
2. Press the reset button at anytime to return to the main menu.

NOTE: Powering the units "OFF". Always power "OFF" all three units when not in use.

NOTE: The Wireless Baseball game system uses infrared technology. Always play with the infrared sensor directly in front of you.

dreamGEAR®
www.dreamgear.net

**FOR TECHNICAL SUPPORT
PLEASE CONTACT: 1-877-999-DREAM
or support@dreamgear.net**